

How to update the software on your Roku streaming device

All Roku TV™ models and Roku® streaming players are designed to ensure they are always running the latest version of software. Your Roku device will check to see whether new software is available for download during initial setup and whenever the Roku device is powered on, and then randomly every 24-36 hours. The download and installation are done automatically without ever interrupting your use of the Roku device. Any Roku peripherals, such as Roku wireless speakers or a Roku subwoofer, will automatically be updated alongside your TV or streaming player.

- ① **Note:** If you are unable to connect your Roku TV system to the internet, you may be able to [update the TV software using USB](#).

For help with a Roku camera, video doorbell, bulb, plug, or light strip, learn how to [update the software on a Roku Smart Home device](#).

How to check for updates on your streaming device

You may want to manually check for an update if:

- Your Roku device has been disconnected for an extended period of time.
- You recently installed an app from the Streaming Store.

Follow the instructions below to manually check for software and app updates.

- 1 Press **Home**  on your Roku remote
- 2 Scroll and select **Settings**
- 3 Select **System**
- 4 Select **Software update**
- 5 Select **Check Now** to manually check for updates

- ① **Tip:** The System update screen displays the current software and build version, along with the date and time of the latest update.

If there is new software available or there are updates for your apps, then your Roku device will download and install them automatically and once completed, your device will reboot.

If you are installing apps and need help, review the steps for [adding apps to your Roku streaming device](#).

Last updated at 6/24/2026 11:00:43 PM

Was this article helpful?

Yes, thanks!

Not really

In this article

[How to check for updates on your streaming device](#)

Related articles

[Update the software on your smart home devices](#)

When you launch the Roku® Smart Home mobile app for iOS® and Android™, you may see a prompt telling you that a software update is

Sound mode is missing

Manufacturers design Roku TV Ready soundbars with unique, built-in sound modes that let you tailor the audio experience based on the ™

Control your streaming devices with Google

When you use Google with Roku ® Voice, you can speak commands like “Hey Google, show me action movies on bedroom Roku” or “Hey Google,

Need more help?



Chat with us

Get help from our support bot or connect to an advisor.

[Start chatting](#)

☐ Stay updated on news and offers

Enter your email address >



 **Roku** Blog >

Roku Experience



Products



Support



Company



Partners



Blog

